

Die Attach Paste ABP8142B Application Data Package (Version 1)

Carol Liu, Wei Yao and Leo Zhou
Shanghai, Sep 2014

Contents

1. Product description & key material properties
2. Cure profile study
3. Dispensing
4. Resin bleed out (RBO) evaluation
5. Work life evaluation
6. Adhesion performance
7. Warpage
8. Open time and stage time study
9. Oven environment study
10. Appendix

Product description & key material properties

Product description & key material properties

-- Product Description

- Henkel Die attach paste ABP8142B is developing a silicone material technology for MEMS application which can offer low modulus / stress, no bleed and higher adhesion.
- ABP8142B is recommended for BT substrate;
- Trail run Cu and PPF L/F performance

Product description & key material properties

-- key Material Properties

Item	ABP8142B	Competitor	Item	ABP8142B	Competitor			
Base Resin	Silicone	Silicone	Adhesion Die: 2X2mm	BT	RT DSS (Kg)	3.60	3.00	
Filler type	Silicon	Silicon			HDSS @260C (Kg)	2.22	2.77	
Density / Specific Gravity (g/cc)	1.17	1.25			HWDSS @260C (Kg)	2.04	1.06	
Viscosity @ 25 °C(cps) (@5rpm)	15500	34000		Cu L/F	RT DSS (Kg)	4.19	2.78	
Thixotropic Index	3.6	3.4			HDSS @260C (Kg)	2.67	2.52	
Working Life @ 25 °C(hours)	48	48			HWDSS @260C (Kg)	3.03	3.60	
DSC onset point (°C)	122.8	125.5		PPF L/F	RT DSS (Kg)	4.60	4.58	
DSC peak (°C)	128.2	128.5			HDSS @260C (Kg)	2.14	3.80	
DSC Delta H (J/g)	26.0	26.2			HWDSS @260C (Kg)	3.15	2.96	
Tg (oC)	-55.5	-57.3		RBO (%)	After	BT	No	No
CTE Above Tg (ppm/ oC)	345	295		Cure condition 150C@30min	Cu L/F	5.37	6.33	
Dynamic Tensile Modulus (Mpa)	@ -65 oC	16.22			33.83	PPF L/F	5.68	4.39
	@ 25 oC	2.25	10.09		Noddle ID size range	>0.26mm	>0.34mm	
	@ 150 °C	2.25	9.56	Dispensing	Fail rate (on noddle size: 0.41mm)	8.89%	20.30%	
	@ 200 °C	2.49	9.72	Warpage (um) Henkel BT substrate (5x5mm with 6mil die)	1.649	1.374		
	@ 250 °C	2.66	11.4	Open time (hours) (at least)	2	NA		
Weight loss on cure (% by weight)	1.42	0.12	Stage time (hours) (at least)	6	NA			
Dielectric constant	3.00	2.90	Hardness Shore A	42	72			

Cure profile study

Cure profile study

-- DOE design

StdOrder	RunOrder	CenterPt	Blocks	Temperature	Time	HDSS@260C
5	1	0	1	150	60	
1	2	1	1	125	30	
4	3	1	1	175	90	
3	4	1	1	125	90	
2	5	1	1	175	30	

Full Factorial Design

Factors: 2 Base Design: 2, 4
Runs: 50 Replicates: 10
Blocks: 1 Center pts (total): 10

- L/F: Henkel in-house BT substrate
- Die: 2x2 mm with 15mil thickness
- Sample size: 10 unites/leg

Cure profile study

-- DOE design

Factorial Fit: 260C@HDSS versus Temperature, Time

Estimated Effects and Coefficients for 260C@HDSS (coded units)

Term	Effect	Coef	SE Coef	T	P
Constant		1799.49	63.94	28.14	0.000
Temperature	234.64	117.32	63.94	1.83	0.073
Time	102.78	51.39	63.94	0.80	0.426
Temperature*Time	-63.47	-31.73	63.94	-0.50	0.622
Ct Pt		-38.56	142.98	-0.27	0.789

S = 404.407 PRESS = 8891079
R-Sq = 8.78% R-Sq(pred) = 0.00% R-Sq(adj) = 0.67%

Analysis of Variance for 260C@HDSS (coded units)

Source	DF	Seq SS	Adj SS	Adj MS	F	P
Main Effects	2	656183	656183	328092	2.01	0.146
2-Way Interactions	1	40278	40278	40278	0.25	0.622
Curvature	1	11897	11897	11897	0.07	0.789
Residual Error	45	7359536	7359536	163545		
Pure Error	45	7359536	7359536	163545		
Total	49	8067894				



Unusual Observations for 260C@HDSS

Obs	StdOrder	260C@HDSS	Fit	SE Fit	Residual	St Resid
2	2	1065.60	1897.15	127.88	-831.55	-2.17R

R denotes an observation with a large standardized residual.


Estimated Coefficients for 260C@HDSS using data in uncoded units

Term	Coef
Constant	612.013
Temperature	7.23130
Time	8.0596
Temperature*Time	-0.0423100
Ct Pt	-38.562



Cure profile study

-- DOE design



- HDSS have no such significant main effect .
- Residual plot show the residual matching the criteria of random distribution, symmetry zero, fitting balance and no special trend.
- HDSS have no significant difference by temperature and time increasing (temperature:125C~175C, time: 30~90mins) ;


Cure profile study

-- DOE design

One-way ANOVA: 125C@30min, 125C@90min, 150C@60min, 175C@30min, 175C@90min


Source	DF	SS	MS	F	P
Factor	4	708358	177089	1.08	0.376
Error	45	7359536	163545		
Total	49	8067894			

S = 404.4 R-Sq = 8.78% R-Sq(adj) = 0.67%



Cure profile have no significant difference

Pooled StDev = 404.4



- Normal customer profile: 150C@30min
- 150C@30min as cure profile evaluated

Cure profile study

-- Summary

- Based on DOE data analysis, ABP8142B: 30mins ramp to 150C, then hold 30min on 150C as cure profile to evaluate;

Dispensing

Dispensing

-- Dot Dispensing Test Methodology

- Totally dispensing 9 groups, 25 dots each group. Each group has the same parameters except different nozzle retract distance, from high to low. Earlier failure, worse dispensing performance

Group 1	Group 2	Group 3	Group 4	Group 5	Group 6	Group 7	Group 8	Group 9
11.4mm	10.2	8.89	7.62	6.35	5.08	3.81	2.54	1.27mm



Good Sample



Fail Sample

Dispensing

-- Plan

- Test Sample: ABP8142B & competitor
- Machine: CAMLOT FX-D
- Nozzle size checked: dispensing performance
- Sample size: 3 strips each batch, total 675 dots each



Dispensing

-- Nozzle size checked

Paste type	Needle ID size			
	0.21mm (#27)	0.26mm (#25)	0.34mm (#23)	0.41mm (#22)
ABP8142B	Fail	Pass	Pass	Pass
Competitor	Fail	Fail	Pass	Pass

- ABP8142B nozzle size: > ID: 0.26mm(#25)
- Competitor nozzle size: ID > 0.34mm(#23)

Dispensing

-- Dot dispensing results (ID: #22)



Dispensing


-- Dot dispensing results

One-way ANOVA: ABP8142B T0, Competitor T0, ABP8142B T24, Competitor T24

Source	DF	SS	MS	F	P
Factor	3	0.040591	0.013530	43.03	0.000
Error	8	0.002515	0.000314		
Total	11	0.043106			

S = 0.01773 R-Sq = 94.17% R-Sq(adj) = 91.98%

Individual 95% CIs For Mean Based on Pooled StDev



Pooled StDev = 0.01773

Paste	Total Dispensing Dot	Defective Dot	Fail Rate
ABP8142B T0	675	60	8.89%
ABP8142B T24	675	58	8.59%
Competitor T0	675	137	20.30%
Competitor T24	675	138	20.44%

- ABP8142B is better than Competitor
- T0 and T24 have no significant difference


Dispensing

-- Summary

- Noddle size application:
 - ABP8142B noddle size: > ID: 0.26mm(#25)
 - Competitor noddle size: ID > 0.34mm(#23)
- Dispensing performance: ABP8142B is better than Competitor; and T0 and T24 have no significant difference;


Resin Bleed out (RBO) Evaluation

Resin Bleed out (RBO) Evaluation -ABP8142B




- No RBO on BT, slight RBO on Cu and PPF after 2hr and cure, RBO rate: 1.6~9%

Resin Bleed out (RBO) Evaluation - Competitor



- No RBO on BT, slight RBO on Cu and PPF after 2hr and cure, RBO rate: 2.1~8.4%

Resin Bleed out (RBO) Evaluation - compared



- On Cu L/F: ABP8142B and Competitor have no significant difference
- On PPF L/F: RBO rate: Competitor is better than 8142B

Resin Bleed out (RBO) Evaluation

-- Summary

- ABP8142B has excellent RBO performance on BT substrate
- ABP8142B has slight RBO on Cu and PPF after 2hr and cure, RBO rate: 1.6~9%
- Compared with Competitor:
 - ABP8142B have no significant difference on BT and Cu L/F
 - On PPF L/F: ABP8142B RBO a little higher than Competitor

Work Life Evaluation


Work Life Evaluation

-- Work Life Definition

- Henkel define the product's work life by chemical work life
 - ✓ Chemical work life is determined by under room temperature, the viscosity increase is less than 25%

Work Life Evaluation

-- Viscosity increasing @ Different Temperature



- The viscosity increase are all smaller than 25% work life at least 48hours

Work Life Evaluation

-- Summary

- ABP 8142B has 48 hours work life at room temperature and the viscosity increase is smaller than 25% within 48 hours


Adhesion performance

Adhesion performance

-- DOE plan and flow

- Adhesion compared: RT, HDSS and HWDSS by difference L/F
- Paste: ABP8142B and Competitor
- L/F: Henkel in-house BT Cu/PPF L/F
- Die thickness: 15mil
- Curing profile: 30min ramp up to the setted temperature, hold 30min
- PMC: 175 °C, 4 hours
- Sample size: 10 unites/leg

• Test flow



HDSS: hot die shear strength

HWDSS: hot wet die shear strength, after parr bomb.

Adhesion performance

-- BLT, fillet checked

ABP8142B

Competitor


Top view

Side view




Top view

Side view

BT




Cu/PPF



- BLT control: ~25um

Adhesion performance

-- RT DSS results analysis



- BT: ABP8142B > Competitor;
- Cu L/F: ABP8142B > Competitor;
- PPF L/F: ABP8142B \approx Competitor;

Adhesion performance

-- RT DSS result analysis

General Linear Model: RT versus L/F, Paste

Factor	Type	Levels	Values
L/F	fixed	3	BT, Cu, PPF
Paste	fixed	2	ABP8142B, competitor


Analysis of Variance for RT, using Adjusted SS for Tests						
Source	DF	Seq SS	Adj SS	Adj MS	F	P
L/F	2	19515644	19515644	9757822	79.06	0.000
Paste	1	7073628	7073628	7073628	57.31	0.000
L/F*Paste	2	4870468	4870468	2435234	19.73	0.000
Error	54	6664852	6664852	123423		
Total	59	38124591				

S = 351.316 R-Sq = 82.52% R-Sq(adj) = 80.90%

Unusual Observations for RT



Obs	RT	Fit	SE Fit	Residual	St Resid
2	3901.60	2985.82	111.10	915.78	2.75 R
8	3656.20	2985.82	111.10	670.38	2.01 R

R denotes an observation with a large standardized residual.



Adhesion performance


-- RT DSS result analysis



- RT SS have such significant main effect with L/F and paste type, and the interaction are also very significant.
- Residual plot show the residual matching the criteria of random distribution, symmetry zero, fitting balance and no special trend.
- 1) RT DSS compared by paste: ABP8142B > Competitor;
2) RT DSS compared by L/F: PPF > Cu > BT

Adhesion compared

-- HDSS results analysis



- BT: Competitor > ABP8142B;
- Cu L/F: ABP8142B ≈ Competitor;
- PPF L/F: Competitor > ABP8142B;

Adhesion performance

-- HDSS result analysis

General Linear Model: HDSS versus L/F, Paste

Factor	Type	Levels	Values
L/F	fixed	3	BT, Cu, PPF
Paste	fixed	2	ABP8142B, competitor

Analysis of Variance for HDSS, using Adjusted SS for Tests


Source	DF	Seq SS	Adj SS	Adj MS	F	P
L/F	2	2504040	2504040	1252020	16.45	0.000
Paste	1	7076375	7076375	7076375	93.00	0.000
L/F*Paste	2	8258482	8258482	4129241	54.27	0.000
Error	54	4108888	4108888	76091		
Total	59	21947785				

S = 275.845 R-Sq = 81.28% R-Sq(adj) = 79.55%

Unusual Observations for HDSS



Obs	HDSS	Fit	SE Fit	Residual	St Resid
11	2771.10	2142.08	87.23	629.02	2.40 R
23	1228.90	2142.08	87.23	-913.18	-3.49 R
35	1249.60	2142.08	87.23	-892.48	-3.41 R

R denotes an observation with a large standardized residual.



Adhesion performance


-- HDSS result analysis



- RT SS have such significant main effect with L/F and paste type, and the interaction are also very significant.
- Residual plot show the residual matching the criteria of random distribution, symmetry zero, fitting balance and no special trend.
- 1) HDSS compared by paste: Competitor > ABP8142B;
2) HDSS compared by L/F: PPF > Cu > BT

Adhesion compared

-- HWDSS results analysis



- BT: ABP8142B > Competitor;
- Cu L/F: Competitor > ABP8142B;
- PPF L/F: ABP8142B ≈ Competitor;

Adhesion performance

-- HWDSS result analysis

General Linear Model: HWDSS versus L/F, Paste

```
Factor Type Levels Values
L/F fixed 3 BT, Cu, PPF
Paste fixed 2 ABP8142B, competitor
```

Analysis of Variance for HWDSS, using Adjusted SS for Tests


Source	DF	Seq SS	Adj SS	Adj MS	F	P
L/F	2	36248691	36248691	18124345	158.24	0.000
Paste	1	622079	622079	622079	5.43	0.024
L/F*Paste	2	6036479	6036479	3018240	26.35	0.000
Error	54	6185193	6185193	114541		
Total	59	49092443				

S = 338.438 R-Sq = 87.40% R-Sq(adj) = 86.23%

Unusual Observations for HWDSS


Obs	HWDSS	Fit	SE Fit	Residual	St Resid
18	1981.80	2964.54	107.02	-982.74	-3.06 R
30	1558.50	2964.54	107.02	-1406.04	-4.38 R

R denotes an observation with a large standardized residual.



Adhesion performance










-- HWDSS result analysis



- RT SS have such significant main effect with L/F and paste type, and the interaction are also very significant.
- Residual plot show the residual matching the criteria of random distribution, symmetry zero, fitting balance and no special trend.
- 1) HWDSS compared by paste: ABP8142B > Competitor;
2) HWDSS compared by L/F: Cu>PPF>BT










Adhesion performance

-- Fail mode-ABP8142B

ABP8142B	RT	HDSS	HWDSS
BT	 <p>Cohesive</p>	 <p>Cohesive</p>	 <p>Cohesive</p>
Cu	 <p>Cohesive</p>	 <p>Cohesive</p>	 <p>Adhesive to L/F</p>
PPF	 <p>Cohesive</p>	 <p>Partial adhesive to L/F</p>	 <p>Partial adhesive to L/F</p>

Adhesion performance

-- Fail mode- Competitor

Competitor	RT	HDSS	HWDSS
BT	 <p>Cohesive</p>	 <p>Cohesive</p>	 <p>Cohesive</p>
Cu	 <p>Cohesive</p>	 <p>Adhesive to L/F</p>	 <p>Adhesive to L/F</p>
PPF	 <p>Cohesive</p>	 <p>Cohesive</p>	 <p>Partial adhesive to L/F</p>

Adhesion performance

-- Summary

Based on DOE adhesion data analysis results:

- RT DSS: ABP8142B>Competitor;
- HDSS: Competitor>ABP8142B
- HWDSS: ABP8142B>Competitor


L/F	RT	HDSS	HWDSS
BT	ABP8142B>Competitor or	Competitor >ABP8142B	ABP8142B>Competitor or
Cu	ABP8142B>Competitor or	ABP8142B≈ Competitor	Competitor >ABP8142B
PPF	ABP8142B ≈ Competitor	Competitor >ABP8142B	ABP8142B≈ Competitor

Warpage performance

Warpage

-- Test Plan

- Warpage is an indicator of package stress which is a key factor for reliability. Normally, lower warpage means lower stress
 - Test Sample: ABP8142B & Competitor
 - Lead frame: Henkel BT substrate: 0.26mm thickness;
 - Sample size and test location



- Die: 5X5mm, 6mil thickness
- Curing: 30 min ramp up to 150°C, keep 30 min, Air oven



Warpage

-- Sample prepared: BLT, fillet checked



Top view

Side view

ABP8142B



Competitor




- BLT control: ~25um


Warpage

-- Test machine, method and warpage results trace

2D






Surfcom



Contact method

Test 2 line



Paste	Trace
ABP8142B	 <p>Smile</p>
Competitor	 <p>Cry</p>

Warpage

-- Results analysis: data analysis: warpage from max data by A and B

Two-Sample T-Test and CI: ABP8142B, Competitor

Two-sample T for ABP8142B vs Competitor


	N	Mean	StDev	SE Mean
ABP8142B	12	1.649	0.562	0.16
Competitor	12	1.374	0.648	0.19

Difference = μ (ABP8142B) - μ (Competitor)

Estimate for difference: 0.275

95% CI for difference: (-0.240, 0.790)

T-Test of difference = 0 (vs not =): T-Value = 1.11 P-Value = 0.280 DF = 21



- ABP8142B and Competitor have no significant difference

Warpage performance

-- Summary


- ABP8142B and competitor have no significant difference on warpage performance

Open Time and Stage Time Study

Open Time and Stage Time Study











-- Open Time

- Open time: The time after dispensing and before die attach, at that time, the paste is open to the environment



Open Time and Stage Time Study


-- Open Time ABP8142B

Open Time	0min	30mins	1hrs	2hrs	4hrs
Top View					
Side View					

- Perfect coverage even after 2 hours open time

Open Time and Stage Time Study


-- Open Time ABP8142B



One-way ANOVA: Open time 0, Open time 0.5, Open time 1, Open time 2h, ...

Source	DF	SS	MS	F	P
Factor	4	10168399	2542100	67.52	0.000
Error	35	1317768	37651		
Total	39	11486167			

S = 194.0 R-Sq = 88.53% R-Sq(adj) = 87.22%



Pooled StDev = 194.0


- Die size: 2x2mm die

- There's a trend that the RT die shear strength will drop as time grows, and after 4 hours open time, the influence will become significant

Open Time and Stage Time Study


-- Stage Time

- Stage time: After die attach, it will take some time to put the packages into oven, and the time is called stage time



Open Time and Stage Time Study

-- Stage Time-ABP8142B



One-way ANOVA: Stage time 0, Stage time 1, Stage time 2, Stage time 4, ...

Source	DF	SS	MS	F	P
Factor	4	10555813	2638953	34.62	0.000
Error	35	2667829	76224		
Total	39	13223642			

S = 276.1 R-Sq = 79.83% R-Sq(adj) = 77.52%

Level	N	Mean	StDev	Individual 95% CIs For Mean Based on Pooled StDev
Stage time 0	8	2872.4	409.9	(---*---)
Stage time 1hrs	8	3048.5	102.6	(---*---)
Stage time 2hrs	8	2866.0	157.3	(---*---)
Stage time 4hrs	8	3715.6	396.4	(---*---)
Stage time 6hrs	8	4146.6	143.9	(---*---)

Pooled StDev = 276.1

- Die size: 2x2mm die

- No adhesion decrease after 6 hours stage time

Open and stage time Performance

-- Summary

- Open Time: ABP8142B after 4 hours open time, adhesion have significant drop, so open time at least 2 hours;
- Stage Time: ABP8142B have no adhesion decrease even after 6 hours stage time

Oven Cure Environment Study

Air Vs N₂

Oven Cure Environment Study

-- Plan

- **Environment: Air Vs N₂**

- Adhesion compared: RT, HDSS and HWDSS

- L/F: Henkel in-house BT Cu/PPF L/F


- Die thickness: 15mil

- Curing profile: 30min ramp up to the setted temperature, hold 30min

- PMC: 175 °C, 4 hours

- Sample size: 10 unites/leg

- Test flow



HDSS: hot die shear strength

HWDSS: hot wet die shear strength, after parr bomb.

Oven Cure Environment Study

-- Adhesion compared

Two-Sample T-Test and CI: Air RT, N2 RT

Two-sample T for Air RT vs N2 RT

	N	Mean	StDev	SE Mean
Air RT	10	3607	435	137
N2 RT	10	3098	428	13

Difference = μ (Air RT) - μ (N2 RT)

Estimate for difference: 509

95% CI for difference: (103, 916)

T-Test of difference = 0 (vs not =): T-Value = 2.64 P-Value = 0.017 DF = 17

Two-Sample T-Test and CI: Air HDSS, N2 HDSS

Two-sample T for Air HDSS vs N2 HDSS

	N	Mean	StDev	SE Mean
Air HDSS	10	2132	276	87
N2 HDSS	10	1998	103	33

Difference = μ (Air HDSS) - μ (N2 HDSS)

Estimate for difference: 133.6

95% CI for difference: (-71.7, 339.0)

T-Test of difference = 0 (vs not =): T-Value = 1.43 P-Value = 0.180 DF = 11

Two-Sample T-Test and CI: Air HWDSS, N2 HWDSS

Two-sample T for Air HWDSS vs N2 HWDSS

	N	Mean	StDev	SE Mean
Air HWDSS	10	1911	394	125
N2 HWDSS	10	1791	281	89

Difference = μ (Air HWDSS) - μ (N2 HWDSS)


Estimate for difference: 120

95% CI for difference: (-204, 445)

T-Test of difference = 0 (vs not =): T-Value = 0.78 P-Value = 0.444 DF = 16

Oven Cure Environment Study

-- Adhesion compared



Oven Cure Environment Study


-- Summary

- ABP8142B Air environment is better than N2 environment, based on adhesion test results:
 - ✓ RT DSS: Air > N2
 - ✓ HDSS: Air ≈ N2
 - ✓ HWDSS: Air ≈ N2
- ABP8142B recommend to cure in Air environment

Appendix


Appendix

-- DSC-ABP8142B




Appendix

-- TGA-ABP8142B




Appendix

-- DMTA-ABP8142B




Appendix

-- DSC- Competitor




Appendix

-- TGA- Competitor



Appendix

-- DMTA- Competitor



Thank you!